

20m Auto Retract Wall Mounted Garden Hose Reel

User Guide



PARTS LIST:

















1/2"-3/4" Tap Adaptor

Wall Bracket

Pivot Bar

Spray Nozzle

Wall Plug and Screw Set

Warning

- If the hose or reel becomes damaged, do not attempt to repair. Please report any faults to Water Irrigation via www.waterirrigation.co.uk/contacts
- Do not attempt to open the hose reel box, due to the springs inside.
- Not suitable children under 16-years old, unless supervised.

1. INSTALLATION


> Choose a suitable position on your wall. Consider the length of the connection hose and allow room for the hose reel to pivot 180 degrees.

> Mark and drill 4 holes to correspond with the positions of the holes in the wall bracket (1).(Note - While the wall bracket can be mounted on other secure structures, the fixings


included are only suitable for standard brick and concrete surfaces)

> Ensure the size of the holes are suitable for the plastic wall plugs (4) included. Insert the plastic wall plugs (4) into the holes.


(Note: Fix the wall bracket (1) facing upwards).



> Fix the bracket to the wall using the screws provided.



> Align the hose reel with the vertical holes in the wall bracket (1) and insert the pivot bar through the wall bracket (1) and reel.



> The connection hose (5) is fitted with quick click connectors. Connect the threaded tap connector to your tap and then attach the quick click connectors from the connection hose (5).
> Turn the tap on and run the water. Check for any leaks and re-tighten any hose connections if required.

(Note: The water flow can be regulated by twisting the end of the spray nozzle.)

2. OPERATION

This hose reel system is equipped with a click-lock mechanism. To operate, pull the hose out to the desired length. When you stop pulling, the hose will automatically stop. To engage the automatic hose recoil, give it a short sharp pull and you will feel the hose automatically retract. Always hold onto the hose nozzle when retracting the hose and walk it back to the hose reel. You can interrupt this process by pulling the hose again.

In order to retract the hose safely, please ensure you keep hold of the hose end while waking towards the hose reel. Letting go of the hose, may result injury.

3.MAINTENANCE

1). It is recommended to turn off water flow at your garden tap before retracting the hose.

2). Before the start of winter, ensure the hose is completely drained of water and remove the hose reel from the bracket and store in a frost-free location.